

Strain Gauge Analog Amplifier with Differential Output



FEATURES

- Differential Input, Differential Output
- Ultra low noise output
- Up to 50 kHz bandwidth
- ±5 or ±10 VDC Outputs
- Bridge Excitation: 5 or 10 VDC (DIP Switch)
- Ranges: 0.5, 1.0, 1.5, 2.0, 2.5, 3.0, 4.0, 10.0 mV/V (DIP Switch)
- 256 Selectable Shunt Combinations: 30kΩ, 43.7kΩ, 60.4kΩ, 87.6kΩ, 100kΩ, 150kΩ, 300kΩ, 432kΩ (DIP Switch)
- 5 Selectable Bandwidths (DIP Switch)
- Externally Accessible Shunt Cal Activation
 Button
- Internal Span and Offset Potentiometers
- Sensor Polarity Reversal DIP Switch

IMPORTANT NOTE: DO NOT CONNECT DEVICE TO POWER SUPPLY WHEN POWER SUPPLY IS ALREADY ON.

OUTPUT IS DIFFERENTIAL. DO NOT CONNECT +/- VOUT TO A GROUND. DOING SO CAN CAUSE DAMAGE.

PARAMETER	MIN.	TYP.	MAX.	UNIT
Power Supply	12.5		26	VDC
Current Consumption		100		mA
Load Impedance	250k			Ohm
Sensor Impedance	350		5000	Ohm
Bandwidth (Setting 1)		100		Hz
Bandwidth (Setting 2)		1000		Hz
Bandwidth (Setting 3)		10000¹		Hz
Bandwidth (Setting 4)		25000²		Hz
Bandwidth (Setting 5)		50000³		Hz
Common Mode Rejection Ratio	120			dB
Noise		2		mVp-p
Output Span range	-10		10	% of FSR
Output Zero range	-10		10	% of FSR
Gain Drift with Temperature	-25	Х	25	PPM of FS
Nonlinearity	-0.01	Х	0.01	% of FSR
Zero Drift with Temperature	-25	Х	25	PPM of FSI
Operating Temperature	32 [0]		158 [70]	°F [°C]
Storage Temperature	-40 [-40]		185 [85]	°F [°C]
Relative Humidity		95% at 100 [39]		°F [°C]
PHYSICAL FEATURES				
Material	Stainless steel cover with aluminum body fastened by magnets			
Protection	IP50			
Weight (approx.)	0.24 lb (109 g)			
Power	LED Indicator			
CONFORMITY				
RoHS	2011/65/EU			
CE		13; EN55011:2009 (ation for Aerospace		

¹ Only for Sensitivity of 1.0 mV/V or Greater














 $^{^{\}rm 2}$ Only for Sensitivity of 1.5 mV/V or Greater


³ Only for Sensitivity of 2.0 mV/V or Greater

Model IAA300 2


DIMENSIONS inches [mm]



DIP SWITCHES CONFIGURATION



SENSOR SIDE PIN # WIRING CODE 1 **SHIELD** 2 + EXCITATION4 3 + SIGNAL - SIGNAL 4 5 - EXCITATION⁴




⁴ For 6 wire sensors, connect +SENSE to +EXCITATION and -SENSE to -EXCITATION.

Note: Sensor cable shield connections should be grounded on one end, either the sensor side or the IAA sensor input side, to avoid potential ground loops.

SCREW TERMINAL CONNECTIONS
(POWER SIDE)

		•	
PIN#	WIRING CODE		COLOR
1	+Vin	Power Supply	Red
2	Gnd	Power Ground	Black
3	Shunt	Remote Connection	Orange
4	+Vout	Positive Output Connection	Green
5	–Vout	Negative Output Connection	White
6	Shield	Braided Cable Shielding	N/A



Note: Gray screw terminals used for IAA300. Troubleshooting tips can be found within the IAA Series Quick Start Guide.

Visit www.futek.com/iaa/support.aspx to find the IAA Series Quick Start Guide, full product manual, wirinf layout, and gain settings.

Drawing Number: FI1397-B

FUTEK reserves the right to modify its design and specifications without notice. Please visit http://www.futek.com/salesterms for complete terms and conditions.

10 Thomas, Irvine, CA 92618 USA

Tel: (949) 465-0900 Fax: (949) 465-0905











